

3RIVE 3D® Application System Console Operation Guide



DAILY STARTUP:

1. Make sure to have the system in HOLD.
2. Turn on ALL sections.
3. Turn the dial to speed.
4. Press and hold the (+) button until CHARGE appears in the top left screen.
5. Lift the RUN/HOLD switch to RUN.
6. The system is set to a 5-minute CHARGE cycle.
7. Press and hold the (+) button to exit CHARGE.

SPECIAL NOTE:

The first time starting the system, make sure to turn the three-way valve to the 6 o'clock position. Run a CHARGE cycle and wait until you start to get a small consistent stream coming out of the white bypass tube. When you receive a steady stream, turn the valve to the 3 o'clock position. This will allow the chemical to flow into the solution pump.

RINSE CYCLE:

1. Make sure to have the system in HOLD.
2. Turn on ALL sections.
3. Turn the dial to SPEED.
4. Press and hold the (-) button until RINSE appears on the top left screen.
5. Lift the RUN/HOLD switch to RUN.
6. The system is set to a 15-minute RINSE cycle.
7. Press and hold the (-) to exit RINSE.

PRESSURE RELEASE:

1. Make sure the system is in HOLD.
2. Turn on ALL sections.
3. Turn the dial to SPEED.
4. Press and hold the (-) button.
5. DO NOT turn the system to RUN.

CHANGE RATE:

1. Make sure the system is in HOLD.
2. Press and hold the CAL button.
3. A red light will appear.
4. Turn the dial to CUSTOM DATA.
5. At the top left, you will see a green light on CHANNEL 1. This will change CHANNEL 1 settings.
6. Press the CHANNEL view selection button to switch to your chemical rate.
7. Use the (+) and (-) arrows to change rates.
8. After changes are made, press and hold the CAL button. This will bring you back to normal operations setup.

3RIVE 3D® Application System ISO Operation Guide



DAILY STARTUP (CHARGE):

1. Open the 3RIVE 3D® homepage.
2. Select CONFIGURE (wrench and screwdriver icon).
3. Select CHARGE/RINSE.
4. Select CHARGE.
5. The system is set to a 5-minute CHARGE cycle.

SPECIAL NOTE:

The first time starting the system, make sure to turn the three-way valve to the 6 o'clock position. Run a CHARGE cycle and wait until you start to get a small consistent stream coming out of the white bypass tube. When you receive a steady stream, turn the valve to the 3 o'clock position. This will allow the chemical to flow into the solution pump.

RINSE CYCLE:

1. Open the 3RIVE 3D homepage.
2. Select CONFIGURE (wrench and screwdriver icon).
3. Select CHARGE/RINSE.
4. Select CHARGE.
5. The system is set to a 5-minute CHARGE cycle.


PRESSURE RELEASE:

1. Open the 3RIVE 3D homepage.
2. Select CONFIGURE (wrench and screwdriver icon).
3. Select CHARGE/RINSE.
4. Select PRESSURE RELEASE.

NO FLOW OR BLOCK SECTION:

1. Release the pressure. See above mentioned steps.
2. Disconnect the ¼-inch line at the quick connect 90 fitting.
3. Unscrew the inner plastic fitting closest to the "Mixing T."
4. Remove the two-piece liquid orifice and make sure both orifices are clean of particles.

REMINDER: Be sure to clean and check chemical strainer on a regular basis.



Contact your local FMC representative to learn more:

MARCUS BARTLETT
605-301-6069
marcus.bartlett@fmc.com

MATT O'CONNOR
219-312-2423
matthew.oconnor@fmc.com

Visit 3RIVE3D.AG.FMC.COM for additional resources including manuals and installation videos.

Always read and follow all label directions, precautions and restrictions for use. Some products may not be registered for sale or use in all states. FMC, the FMC logo and 3RIVE 3D are trademarks of FMC Corporation of an affiliate. ©2021 FMC Corporation. All rights reserved. 21-FMC-0516 03/21

